

ACCUSPLIT. PRO SURVIVOR STOPWATCH



STOPWATCH OPERATIONS For Typical Uses

Press C until at STOPWATCH display. If necessary, Press R to Stop and L to Reset to zero.

Event	Split	1-2 Finish
R-Start	R-Start	R-Start
R-Stop	L-Split	L-Stop #1
(Repeat R,R time-in/ time-out)	L-Release (Repeat L,L each Split)	R-Stop #2 (See #1 time) L-Release (See #2 time)
L-Reset	R-Stop L-Reset	L-Reset

TIME AND CALENDAR DISPLAY

- Press C, until at TIME display.
- Hold R—display Month, Date and PM indicator (P).
- Hold L—display MEMO TIME (Professional X Stopwatch Series do not have Sound Alarm or Chime).

TO SET TIME AND CALENDAR

- Hold C for 3 seconds and Press C once to enter TIME SET MODE.
- Press R to select Minutes, Hour, Month, Date, Day, Seconds.
- Press L to change any of the above. (Seconds only resets to 00). (Hold L to change digits rapidly).
- Press C to return to TIME display.

TO SET MEMO TIME


- Hold C for 3 seconds to enter MEMO TIME SET MODE.
- Press R to select Minutes and Hours.
- Press L to change Minutes and Hours.
- Press C to return to TIME display.

TO SET 12/24 HOUR FORMAT

- Hold R and Press C to interchange 12P or 24 format.

BATTERY CHANGING

See Specifications panel.



REGISTER NOW Please return your AG01X Registration to the Repair Center address in the warranty, & we will let you know about future products.

Email (preferred) _____
User _____

1-800-965-2008 or 1-925-226-0888
FAX: 925-463-0147
repair@accusplit.com
www.accusplit.com

ASSEMBLED IN PRCHINA
© 2004 ACCUSPLIT

SPECIFICATIONS

Batteries: Batteries should last for 3 years. If display becomes dim, open back and replace with Duracell LR44, Eveready A76, or Ray-O-Vac LR44. For longer life, use Silver Oxide Battery.
Operating Temperature: 14°F to 138°F (-10°C to 59°C).
Quartz Crystal Accuracy: 0.1 sec/hr (accuracy may vary with shock, temperature or aging of crystal).