

# ACCUSPLIT EAGLE 602M100D (FY)

## MULTI-FUNCTION STOPWATCH

### STOPWATCH OPERATING INSTRUCTIONS

This watch has three modes—**TIME**, **STOPWATCH**, and **3-STROKE/STRIDE MEASUREMENT**. Press the **[MODE]** button to cycle continuously through these modes.

#### TIME MODE

To set current date and time of day, press **[RESET]** button. SECONDS indicator will flash to indicate you are in SET mode.

Press **[RESET]** to cycle through and set each field (SECONDS -> MINUTES -> HOURS -> YEAR -> MONTH -> DAY). Field being set will flash. Press **[START]** button to set each field.

#### STOPWATCH MODE

##### Event and Time-Out/Time-In

Press **[START]**—Start timing

Press **[STOP]**—Stop timing (Time-Out, Display shows “STOP”)

Press **[START]**—Start timing (Time-In)

Press **[STOP]**—Stop timing (Time-Out, Display shows “STOP”)

Press **[RESET]**—Reset (Display Only)

##### Dual Split Memory with Split Counter

Press **[START]**—Start timing (Shows Running CUM Time)

Press **[LAP/SPLIT]**—create 1st Split or Lap time (Top row shows SPLIT 1, middle shows LAP 1, and bottom row shows running cumulative time)

Press **[LAP/SPLIT]**—create 2nd Split (Top row shows SPLIT 2, middle shows LAP 2)

Press **[LAP/SPLIT]**—create 3rd Split (Top row shows SPLIT 3, middle shows LAP 3)

Press **[LAP/SPLIT]**—create 4th Split (Top shows SPLIT 4, middle shows LAP 4)

Press **[STOP]**—Stop timing (Bottom shows Cumulative elapsed time)

Press **[RESET]**—Reset display only (memories remain)

#### Notes:

Bottom row always shows Running Cumulative (CUM) time. Split Counter shows the current Split being taken. Last Split must be taken at end. Stop does not Split.

#### Memory Recall

*While stopwatch is running:*



Press **[RECALL]**—Recalls CUM time at last stop, or last Lap/Split times.

Press **[RECALL]**—Recalls previous Lap/Split/Stop time each time **[RECALL]** is pressed.

*While stopwatch is stopped:*

Press **[RECALL]**—Recalls CUM time at first stop, or first Lap/Split times.

Press **[RECALL]**—Recalls next Lap/Split/Stop time each time **[RECALL]** is pressed.



#### Notes:

Hold down **[RECALL]** for rapid review.

Whenever the storage is full, “FULL” icon will be lit, and extra Split times will not be stored into memory (but will still be shown on the display). You can clear the memories by stopping and resetting the watch.

#### 3-STROKE/STRIDE MEASUREMENT MODE

In this mode you can find Counts per Minute (frequency) of a swimmer's strokes, a runner's strides, etc. Press **[START]** to start the measurement. After you have observed THREE strokes or strides, press **[STOP]** to stop and display the Counts per Minute (rate). **NOTE:** If the stroke frequency falls out of the range of 10-180, “Err” will appear to show the error condition. Press **[RESET]** to reset the displayed reading to “0\_0”.